

Fitting Instructions – IGNITE 3" & 3.5" Exhaust System

Vehicle Application: Ford Ranger Next Gen V6 3.0L

Before You Begin:

Ensure the vehicle is securely parked on a flat surface and safely supported. Always allow the exhaust system to cool down before commencing removal or installation.

Installation Steps

1. Remove Factory Exhaust Components (3" & 3.5" Systems)

Remove the factory muffler and tailpipe assembly.

- *3" System:* The new exhaust will slide into the factory slip joint where the original band clamp is located.
- *3.5" System:* Remove the factory DPF connecting pipe as well as the pressure line attached to it.
Apply lubricant to the rubber hangers to make removal easier.

2. Install DPF Connector Pipe – 3" System

With the factory system removed, install the 3" DPF connector pipe using the original band clamp.

3. Install DPF Connector Pipe – 3.5" System

With the factory system removed, install the 3.5" DPF connector pipe using the original three bolts and gasket. Re-attach the pressure hose to the pressure fitting on the pipe.

4. Install Mid Pipe – 3.5" System

Fit the mid pipe section and secure it with the supplied 3/8" UNC bolts and nuts. Ensure the gasket is properly seated between the flanges.

5. Install Tailpipe – 3" & 3.5" Systems

Install the tailpipe section and fasten it using the supplied 3/8" UNC bolts and nuts. Confirm the gasket is correctly positioned between the flanges.

6. Check Clearances

Ensure all components have adequate clearance from surrounding vehicle parts.

7. Start-Up & Leak Inspection

Start the vehicle and check all connections for leaks. Adjust as required.

8. Completion

Enjoy your new IGNITE Exhaust system.