



Mazda BT50 3.2L 2016 onwards DPF Model

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting/DPF pipe from the vehicle.
3. Using the factory DPF flange nuts fit the DPF pipe and tighten finger tight.
4. Fit the tailpipe to the DPF pipe and tighten finger tight with the supplied 3/8 UNC nuts.
5. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
6. Enjoy your IGNITE exhaust!