



Nissan Navara D40 2.5L 2007-2014 NON DPF model (Manual)

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting pipe from the vehicle.
3. Remove flex join pipe from the vehicle.
4. Remove turbo dump pipe heat shields.
5. Remove gear box bracket.
6. Remove turbo dump pipe. We advise to spray the 3 nuts with WD40 before removing.
7. Insert the supplied EGT plug into the turbo dump pipe.
8. Fit the turbo dump pipe cat/cat delete section to the turbo outlet flange using the three supplied M10x1.25 nuts. Re fit gear box bracket at the same time and then tighten all 4 nuts/bolts.
9. Fit the flex join pipe to the turbo dump pipe cat/cat delete section and tighten finger tight with the supplied 3/8 UNC nuts.
10. Fit the connecting pipe to the flex pipe (the larger degree bend will connect onto the flex pipe) and tighten finger tight with the supplied 3/8 UNC nuts.
11. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts.
12. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
13. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
14. Enjoy your IGNITE exhaust!